Drilling Fixture for Cam Lock Furniture Assembly

Complete set: drills, 10 locks, 10 lock pins, 20 dowels. Includes adjustment fixture and tools for wooden furniture assembly.







Complete set with drilling fixtures, drills, locks, lock pins, and dowels, typically used for assembling wooden furniture.

Includes:

- 10 locks
- 10 lock pins
- 20 dowels
- Drill for locks
- Drill for lock pins
- Drill for dowels
- Fixture with adjustment tools

Buy online at:

www.matronics.eu/A810001



Drilling Fixture for Cam Lock Furniture Assembly

SKU A810001

Product pictures





